

MAINTAINING YOUR SPORTS SURFACE

Daily Cleaning

Use a V mop to sweep the floor, collecting all surface dust / debris and remove. This should be undertaken at least once a day during periods of heavy use.

Weekly Cleaning

The floor should be mechanically cleaned once a week or after every 35 hours of use.

- Use a V mop to sweep the floor, collecting all surface dust / debris and remove.
- Clean the floor with Bona SuperSport Cleaner Solution, purchased through Dynamik, using a standard speed rotary scrubber dryer fitted with a red pad.

Deep Cleaning

The floor should be deep cleaned every 3-6 months dependent upon the level of usage.

- Use a V mop to sweep the floor, collecting all surface dust / debris and remove.
- Clean the floor with Bona SuperSport Deep Clean Solution, purchased through Dynamik, using a standard speed rotary scrubber dryer fitted with a red pad.

Additional Maintenance for Timber Surfaces

- To protect and maintain the finish of your DYNAMIK Sports Floor, a scrub and re-lacquer seal coat will need to be applied every 2-3 years. Please contact DYNAMIK to arrange this.
- A DYNAMIK Sports Floor will need to be sanded and re-lacquer sealed for the first time after 10-12 years in a sports only facility or after 8-12 years in a high usage, multi-use facility. Please contact DYNAMIK to arrange this.

General Advice

- Remove spills of tea, coffee, squash etc. with a cloth dampened in warm water. Heavier contamination such as body fats, dirt and grease should be removed using a 'low foam' mild detergent, and then wiped with a clean damp cloth.
- The above should be taken as a general guide since each individual facility will vary, for example if there is an excessive amount of airborne dust a more frequent cleaning regime will be required.
- Should you have any questions then please do not hesitate to contact DYNAMIK.

0117 3015120 - info@dynamiksport.co.uk
www.dynamiksportsfloors.co.uk

DYNAMIK